Hand-Push Scissor Lift 5M

Model SJST-5M — Instruction Manual

MODEL	LIFTING HEIGHT	LOAD CAPACITY
SJST-5M	**5M**	**400KG**



Please read this manual carefully before operating the machine. Improper operation may cause injury or equipment damage. Keep this manual for future reference.

1 Product Overview



The SJST-5M is an electric scissor lift vehicle designed for material handling and aerial working in farms, workshops, warehouses and construction sites. The scissor mechanism lifts the work platform smoothly to a height of 5M, and the electric drive chassis allows the machine to travel with the platform lowered.

Main applications

- Aerial maintenance and installation work
- Picking and pruning in orchards and greenhouses
- Stock taking in high-bay warehouses
- Cleaning and decoration at height

Key features

✓ Hydraulic outriggers for extra stability

✓ Removable platform guardrail

✓ Smooth electric scissor lifting, no exhaust emission

✓ Emergency stop button cuts all power instantly

✓ Configuration can be customized on request

What's in the box

- Complete machine
- Battery charger
- Wireless remote control
- Instruction manual

2 Specifications

Product name	Hand-Push Scissor Lift 5M
Model number	SJST-5M
Lifting height	5M
Overall dimensions (L×W×H)	220*100*165CM
Board size	200*90CM
The board surface is off the ground	85CM
Load range	400KG
Electric motor	1000W
Controller	1000W
Battery	48V20A Storage battery
Control method	Handlebar+remote control button

All parameters are manually measured and may have slight errors. Please refer to the received product for details. Specifications can be customized — contact the seller for special requirements.

Package list

Complete machine	× 1
Battery charger	× 1
Wireless remote control	× 1
Instruction manual	× 1

Optional configuration

Customizable items	Lifting height / platform size / battery capacity / body color — contact the seller with your requirements before ordering.
Spare parts	Batteries, chargers, controllers, hydraulic seals, wheels / tracks are available from the seller.

3 Before First Use

Complete the following checks before operating a new machine. Do not skip any step.

01 Packaging inspection	Check the package for damage during transport. Unpack carefully with the machine upright.
02 Contents check	Confirm the machine, charger, remote control (if equipped), keys and accessories are complete.
03 Visual inspection	Check for deformation, loose bolts or damaged cables caused by transport. Tighten and repair before use.
04 Battery status	The battery is shipped charged at about 60–80%. Fully charge it before first use (see Chapter 7).
05 Tire / track check	Check tire pressure or track tension. Remove wires, stones or ropes wound on the wheels.
06 Function test	Test travel forward / backward, steering, lifting / lowering (or dumping) at low speed without load.

Site requirements

- Use on firm, flat ground with a slope of no more than 15°; avoid steps, ditches and obstacles.
- Keep bystanders, especially children, at least 3 meters away from the working area.
- Do not operate in heavy rain, thunderstorm or on ground covered with ice or grease.
- Ensure adequate lighting and visibility when working indoors or at night.

4 Operating Instructions

Starting	Turn on the power switch and check the battery indicator. Confirm the emergency stop button is released.
Traveling	Slowly twist the throttle (or press the travel button) to move. The lifting platform must be fully lowered while traveling.
Positioning	Park the machine, and if equipped with hydraulic outriggers, extend all outriggers until the wheels are slightly off the ground.
Lifting	Press the lift-up button on the remote or handlebar to raise the platform. Keep all persons clear of the scissor area.
Working at height	Do not move the machine while the platform is raised. Do not overload beyond the rated capacity.
Lowering	Press the lift-down button to lower the platform slowly. Retract the outriggers (if any) before traveling again.

> Never allow untrained persons to operate the machine. The operator must be 16 years or older and in good physical condition.

Working conditions

- Rated load: **400KG**. Overloading is strictly prohibited.
- Maximum climbing ability depends on load and battery level — always climb slowly and straight.
- Stop using the machine immediately if abnormal noise, smoke or smell occurs.

Transport & storage

- Fix the machine with straps during transport; do not lift it by the hoses, cables or guardrails.
- Store indoors in a dry, ventilated place, away from rain, direct sunlight and corrosive materials.
- For long-term storage, fully charge the battery and recharge it at least once a month.
- Lower the platform / bucket completely and turn off the main power before storage.

5 Control Method

The handlebar twist grip controls travel; the wireless remote control buttons raise and lower the platform, allowing operation from a safe distance.

Control method	Handlebar+remote control button
Power switch	Main power key switch on the battery box / frame
Emergency stop	Press the red emergency stop button to cut all power instantly
Charging port	Charging socket on the machine body — see Chapter 7

6 Safety Precautions

General

- Read this manual completely before first operation.
- Do not modify the machine or its electrical system by yourself.
- Keep hands, feet and clothing away from the scissor arms, wheels and moving parts.
- Do not operate the machine under the influence of alcohol or medicine.
- Do not carry passengers unless the machine is designed with a seat.
- Keep children and untrained persons away from the machine.

Electrical & battery

- Only use the original charger and correct voltage.
- Keep the battery away from fire, water and metal objects.
- Do not touch exposed wires or the controller with wet hands.
- Turn off the power before cleaning or maintenance.
- Stop charging immediately if the battery heats abnormally or smells.
- Do not use the machine during thunderstorms.

> **WARNING:** Do not drive the machine with the platform raised. Failure to follow the safety instructions may cause serious injury.

Emergency handling

- **Machine out of control:** press the emergency stop button immediately and keep away from the machine.
- **Unexpected lifting / tipping:** keep all persons clear of the danger zone; do not try to catch the load by hand.
- **Battery smoke or fire:** cut off the main power and use a dry-powder extinguisher; never use water.
- **Injury:** stop the machine and seek medical help at once; keep the accident scene for after-sales analysis.

7 Battery & Charging

Battery configuration: **48V20A Storage battery**. Follow the rules below to extend battery life.

- Charge the battery after each use. Avoid deep discharge below 20%.
- Charging time is typically 6–10 hours. Disconnect the charger when fully charged.
- Charge in a dry, ventilated place away from flammable materials.
- If the machine is stored for a long time, charge the battery at least once every month.
- Do not replace the battery with a different voltage or capacity without consulting the seller.

8 Maintenance Schedule

Daily	Check tire / track condition, clean the machine, check the power connector.
Weekly	Check and tighten bolts on scissor arms, wheels and guardrail; lubricate pins.
Monthly	Check hydraulic oil level and leakage; test the emergency stop and brakes.
Every 6 months	Replace hydraulic oil if contaminated; have the controller checked by a professional.

> Always turn off the main power and remove the key before any maintenance. Repairs to the hydraulic and electrical systems should be performed by qualified technicians only.

Long-term storage

- Clean the machine and park it indoors on a flat, dry surface.
- Charge the battery fully and disconnect the main power switch.
- Recharge the battery at least once a month to prevent deep discharge damage.
- Check and lubricate all pivot points before using the machine again.

9 Troubleshooting

Lift does not rise	Battery low / emergency stop pressed / remote not paired — charge the battery, release the stop button, re-pair the remote.
Lifting is slow or weak	Hydraulic oil low or cold — top up the oil and warm up the machine before working.
Platform drifts down	Hydraulic valve leakage — stop using and contact after-sales.
Machine does not travel	Power off / controller fault — check the battery switch and wiring, contact after-sales if the fault persists.

10 After-sales Service

If the problem cannot be solved with the table above, please contact the seller via AliExpress order message and provide:

- Order number and product model (SJST-5M)
- Photos or a short video of the problem
- Purchase date and a description of how the problem occurred

Spare parts (batteries, chargers, hydraulic seals, controllers, wheels / tracks) are available from the seller. Do not disassemble the core components by yourself, otherwise the warranty may be void.

Warranty & support

- Core components (motor, controller, hydraulic cylinder) are covered by the seller's warranty policy — contact the seller for details.
- Free technical guidance for installation, operation and maintenance via AliExpress order message.
- Consumable parts can be purchased separately at any time.

Thank you for your purchase!

We wish this machine brings you safe and efficient work. Your feedback on AliExpress is highly appreciated.